

WALL MURAL INSTALLATION INSTRUCTIONS



EACH STRIP IS 50 CM WIDE. PLEASE NOTE THAT THE LAST ELEMENT MAY NEED TO BE CUT.

PREPARATION

1 PREPARE THE WALL

The surface should be clean, dry, smooth, and light-colored. It is recommended to apply the mural on an even, primed surface. Before installation, fill any holes, remove dirt, dust, grease stains, or uneven areas. Remove any protruding elements from the wall, such as skirting boards, screws, sockets, and switches.

2 CHECK THE WALL MURAL

Unroll the mural on a clean, dry, and flat surface with the printed side facing up. If the mural consists of multiple panels, check their order and pattern alignment before starting. Inspect the product for any manufacturing defects. In case of any issues – contact us before installation.

3 CHECK ROOM CONDITIONS

Due to the drying process of the adhesive, it is not recommended to install the mural in rooms with very low humidity or at temperatures below 10°C (50°F). The optimal room temperature for installation and drying is between 18–21°C (64–70°F).

REQUIRED MATERIALS



Wallpaper adhesive



Adhesive tray



Pencil



Painter's tape (optional)



Ruler / measuring tape



Spirit level or plumb line



Utility knife



Adhesive brush




Wallpaper roller or brush



Soft, damp sponge or cloth

STEP-BY-STEP INSTALLATION

1



Using a spirit level and ruler, lightly draw vertical guide lines with a pencil where the wallpaper panels will be placed (every 50 cm).


2



Prepare the adhesive. If using the adhesive supplied with the mural, follow these instructions:

1. Slowly pour the contents of the sachet into 1L of cold water while stirring vigorously.
2. Keep the sachet close to the water surface while pouring.
3. Let it sit for 3 minutes, then stir again.
4. Let it sit for 15 minutes and stir thoroughly the adhesive is ready.


3



Apply a thin, even layer of adhesive directly to the wall using a brush (slightly wider than the panel).

IMPORTANT
Do not apply adhesive to the mural!

4




Start with the first panel. Identify the top side. Roll it with the print facing inward (starting from the bottom). Position the top edge of the panel against the glued wall, aligning it with the vertical line, and gently roll it down while pressing it to the wall.

IMPORTANT

Ensure the first panel is straight. Adjust if needed.

5




Remove air bubbles by gently smoothing the surface from top to bottom and from center to edges with a roller or wallpaper brush.

IMPORTANT

After applying each panel, remove any excess adhesive with a soft, slightly damp sponge or cloth. Do not rub – this may damage the print.

6




Repeat these steps for each additional panel. Continuously check that the panels adhere well and the pattern aligns (view from 1–2 meters away). The panels should not overlap.

IMPORTANT

If you notice any misalignment or gaps, you can still gently adjust freshly applied panels.

7



The last panel may need to be trimmed. If the ordered mural width is not a multiple of 50 cm, the final panel will be too wide and must be cut to fit the remaining wall space.

HOW TO DO IT:

1. Carefully measure the remaining uncovered section of the wall.
2. Place the panel dry (without adhesive) on the wall and align the pattern.
3. Add approx. 2 cm as trimming margin near the wall edge.
4. Mark the cutting line and trim the panel with a utility knife on a safe surface (e.g., a cutting mat or cardboard).
5. Apply adhesive to the wall and mount the last panel as usual. Trim any excess if necessary.
6. Always make sure the pattern matches perfectly before trimming.

IMPORTANT

Upewnij się, że wzór na dociętym pasie idealnie pasuje do poprzedniego – przycinanie wykonuj zawsze po dopasowaniu wzoru.

AFTER INSTALLATION

- 1 Smooth the entire mural once more with a wallpaper roller. Small air bubbles may appear and should disappear within 1–3 days.
- 2 Do not accelerate drying – do not use hair dryers, heaters, or similar devices.
- 3 Keep the room temperature above 10°C (ideally 18–21°C) and ensure proper ventilation.

Avoid intense heating, especially near heaters or radiators.

